



Manual

Inspectors

Eqinfo

Revision	Description	Date	By
1.0	Final	09/08/2019	Gijs van Wijmen
2.0	Update	16/12/2024	Stephan Eekman
3.0	Update	23/03/2026	Stephan Eekman

Table of contents (click on the chapter to go there)

Introduction	4
Miscellaneous	5
Login.....	5
Work faster	5
Create a shortcut.....	5
Remember username and password.....	6
Customize layout	7
Sorting.....	7
Moving columns	8
Adding columns.....	9
Saving a view	10
View Management.....	11
Label printing	11
Desired default settings (settings-layout : Thin Client)	13
Printing single labels	18
Printing a batch of labels	20
1. Objects	22
1.1 Object search.....	22
Filter and click	22
Fast filter	23
1.2 Viewing object information	23
Viewing information for selected lines.....	24
Printing data	24
1.3 Adding or editing objects	25
1.4 Conducting an inspection	26
Inspection in the app (tablet or cell phone)	26
Conducting an inspection in the web version	27
Answering questions	28
Result.....	29
Changing results manually (web version)	30
Closing an inspection	30
Verifying that an inspection has been closed	31
Removing an inspection	31
2. Locations.....	33
2.1 Finding locations	33
2.2 Viewing location data	33

- 3. Relations33
 - 3.1 Finding relations.....33
 - 3.2 Viewing relation data.....33
- 4. Catalog.....34
 - 4.1 Viewing the product catalog by topic34
 - 4.2 Searching for items in the catalog34
- 5. Maintenance.....35
 - 5.1 Inspection35
 - 5.2 Open inspections35

Introduction

This manual is intended for inspectors with rights both to inspect and modify in United Rentals' Eqinfo platform.

Users with these permissions can use the platform for the following:

- Add/modify objects
- Conducting inspections
- Printing new QR labels

It should be kept in mind that the quality of the system is as good as the quality of its management. Users with rights to do inspections and modify are partly responsible for keeping the system up-to-date. So it is very important that you check necessary changes and mutations regularly and make adjustments if needed.


For questions about using the Eqinfo platform send an email to:

bintveld@ur.com

Miscellaneous

Login

The platform can be accessed from any computer or phone with Internet by going to eqinfo.eqin.eu in your browser.




Enter your username and password to log in. You can also click on the icon  in the upper right corner to log in or out.

Work faster


Create a shortcut

Google chrome :



1. Go to eqinfo.eqin.eu
2. Click on the three dots at the top right
3. Select " Cast, save and share "
4. Select " Create shortcut... "


Microsoft Edge :



1. Microsoft Edge is almost always your default browser. Go to your desktop.
2. Click somewhere with your right mouse button.
 - a. Don't click an icon!
3. Select " New "
4. Select " Shortcut "
5. Enter www.eqinfo.eqin.eu
 - a. Or paste the link you copied

Remember username and password

After you have logged in, click on " Save "




Customize layout

Each user can personalize the layout settings of their account to their liking. You can determine which columns you want to see and in what order. In this chapter, you will learn how.

Sorting

You can sort on a column by clicking on it. If you want to sort from Z to A, click on the column again.



ID	Naam
0001	EQJN
00010	EQJN B.V. Botlek
00012	EQJN B.V. Elsloo
00015	EQJN B.V. Geleen
00016	EQJN B.V. Klundert
00017	EQJN B.V. VELSEN
00018	EQJN B.V. ALKMAAR

ID	Naam
19893	3M
00170	Aalsmeer
200245	ABA Vlaardingen
00450	ABIRD
00481	Abuco

ID	Naam
99398	Zwan
99385	Zwaan
99280	Zutphense lasind
117166	Zuidplus
99151	ZPMC
214001	Zon
98810	Zirkzee

Moving columns

You can move a column by dragging it from left to right (or vice versa).

ID	Naam	
0001	EQIN	Theems
00010	EQIN B.V. Botlek	Theems
00012	EQIN B.V. Elsloo	Business
00015	EQIN B.V. Geleen	Koestraat 1
00016	EQIN B.V. Klundert	Kieftweg 13
00017	EQIN B.V. VELSEN	Wenckenbachstraat 1
00018	EQIN B.V. ALKMAAR	Koraalstraat 2 A
0002	Stork HQ Global	

Press and hold




ID	Adres	Naam	Adres
0001		EQIN	Theemsveg 2
00010		EQIN B.V. Botlek	Theemsveg 2
00012		EQIN B.V. Elsloo	Business Park Stein 302
00015		EQIN B.V. Geleen	Koestraat 1
00016		EQIN B.V. Klundert	Kieftweg 13
00017		EQIN B.V. VELSEN	Wenckenbachstraat 1
00018		EQIN B.V. ALKMAAR	Koraalstraat 2 A
0002		Stork HQ Global	

ID	Adres	Naam
0001	Theemsveg 2	EQIN
00010	Theemsveg 2	EQIN B.V. Botlek
00012	Business Park Stein 302	EQIN B.V. Elsloo
00015	Koestraat 1	EQIN B.V. Geleen
00016	Kieftweg 13	EQIN B.V. Klundert
00017	Wenckenbachstraat 1	EQIN B.V. VELSEN
00018	Koraalstraat 2 A	EQIN B.V. ALKMAAR
0002		Stork HQ Global

Adding columns

1. Right-click on any column.
2. Choose Columns.



The screenshot shows a table with the following columns: ID, Description, Object type ID, and Object type description. A context menu is open over the 'Description' column header, with 'Columns' selected. The table contains several rows of data, including items like 'Digital multimeter Fluke 177' and 'Scopemeter Fluke 123'.

<input type="checkbox"/> ID	Description	Object type ID	Object type description
<input type="checkbox"/> 0011		LAS-MIG	Welding equipment
<input type="checkbox"/> 0022		LAS-MIG	Welding equipment
<input type="checkbox"/> 0-045	Digital multimeter Fluke 177	EKK	Electrical inspection
<input type="checkbox"/> 0-073	Scopemeter Fluke 123	EKK	Electrical inspection
<input type="checkbox"/> 01.01.5133		Hijs	Lifting equipment
<input type="checkbox"/> 01.01.5134		Hijs	Lifting equipment
<input type="checkbox"/> 01.01.5135		Hijs	Lifting equipment
<input type="checkbox"/> 01.01.5136		Hijs	Lifting equipment

3. Choose the column you want to add (e.g. object image), check the box and choose "Apply Columns".

Columns ×

Search...

<input type="checkbox"/> AIDC	Left
<input type="checkbox"/> Basic location	Left
<input type="checkbox"/> Basic location description	Left
<input type="checkbox"/> Basic location ID	Left
<input checked="" type="checkbox"/> Brand	Left
<input type="checkbox"/> Brand description	Left
<input type="checkbox"/> Brand ID	Left
<input type="checkbox"/> Condition description	Left
<input type="checkbox"/> Cost estimate description	Left


[Apply columns](#)

4. The column appears on the far right. You can drag it to the left (see [Moving columns](#))

Saving a view

You can save the changes to the layout. This way, you will see your changes when you reload the page.

1. Right-click on any column
2. Choose Settings > Save display as



ID	Description	Object type ID	Object type description	Object type
<input type="checkbox"/> 0011				
<input type="checkbox"/> 0022				
<input type="checkbox"/> 0-045	Digital multimeter Fluke 177	EKK	Electrical inspection + calibration	Electrical inspection + calibration
<input type="checkbox"/> 0-073	Scopemeter Fluke 123	EKK	Electrical inspection + calibration	Electrical inspection + calibration
<input type="checkbox"/> 01.01.5133		Hijs	Lifting equipment (suspended loa...	Lifting equipment (suspended loa...
<input type="checkbox"/> 01.01.5134		Hijs	Lifting equipment (suspended loa...	Lifting equipment (suspended loa...
<input type="checkbox"/> 01.01.5135		Hijs	Lifting equipment (suspended loa...	Lifting equipment (suspended loa...

3. Choose a name for the new view and check " Set as standard view ".

Create a new view



Name

Default



Type of view

User view




Set as standard view

Save


View Management

You can switch between different views in view management.

1. Right-click on any column.
2. Choose Settings > View Management



3. Left-click on a view to apply it.
4. Right-click on a view to set it as the default, or to remove it.




Label printing


The following label printers are currently in use:

- STPR 248 / STWNLCS017: continuous labels Botlek new fleet
- STPR 249 / STWNLCS017: large label with QR code Botlek new fleet
- STPR 250 / STWNLCS017: mini label with QR code Mobile Service Botlek
- STPR 251 / STWNLCS017: mini label with QR code Botlek new fleet
- STPR 252 / AMSPRT01: continuous labels Delfzijl
- STPR 253 / AMSPRT01: large label with QR code Delfzijl
- STPR 255 / AMSPRT01: mini label with QR code Elsloo
- STPR 256 / AMSPRT01: large label with QR code Elsloo
- STPR 257 / AMSPRT01: continuous labels Elsloo
- STPR 258 / AMSPRT01: large label with QR code Antwerp
- STPR 259 / AMSPRT01: mini label with QR code Antwerp
- STPR 260 / AMSPRT01: continuous labels Antwerp
- STPR 347 / AMSPRT01: mini label with QR code Botlek welding machines
- STPR 348 / AMSPRT01: mini label with QR code Botlek welding torches
- STPR 471 / STWNLCS017: mini label with QR code Botlek pneumatics
- STPR 472 / STWNLCS017: mini label with QR code Botlek first line
- STPR 473 / STWNLCS017: mini label with QR code Botlek cables
- STPR 474 / STWNLCS017: large label with QR code Botlek distribution boxes

Click " Start " and type " Printer ". Click on Printers & scanners:





Choose the printer you want to set up, and click on " Printing Preferences "



Desired default settings (settings-layout : Thin Client)

Mini label with QR code :



Printer Settings

Page Setup

Print Options

Device Options

Graphic Options

Custom Commands

Maintenance

Units

Help and About

Print test page

NiceLabel

[Download your trial of NiceLabel Designer](#)

Actions

After print: Cutter

Cutter

Type: Every label


Cut every: 1 labels

Feed offset: 0 mm

Partial cut

Stop on last element

Print preview





OK


Cancel

Apply


Help

Large label with QR code:





Continuous labels :



Printer Settings

- Page Setup
- Print Options**
- Device Options
- Graphic Options
- Custom Commands
- Maintenance
- Units
- Help and About

Print settings

Speed: 51 mm/s

Darkness: 10


Printing mode: Thermal transfer

Position adjustment

Left offset: 0 mm

Top offset: 0 mm

Print preview



Print test page

NiceLabel

[Download your trial of NiceLabel Designer](#)

OK Cancel Apply Help

Printer Settings

- Page Setup
- Print Options**
- Device Options
- Graphic Options
- Custom Commands
- Maintenance
- Units
- Help and About

Print settings

Speed: 51 mm/s

Darkness: 10


Printing mode: Thermal transfer

Position adjustment

Left offset: 0 mm

Top offset: 0 mm

Print preview



Print test page

NiceLabel

[Download your trial of NiceLabel Designer](#)

OK Cancel Apply Help

Printing single labels

Unique objects

1. Go to the object you want to print a label for (see find_objects)
2. Click on the printer icon at the top right and choose the label you want to print.

23080004 - MIG Fronius Transsteel 5000 32A 5P
MIG Fronius Transsteel 5000 32A 5P

Owner	ESOM
ID	23080004
Owner references	
Barcode	
Brand	Fronius
Type	TS 5000
Serial Number	3156296
Construction year	2020
End of life	
Object type	Rental Welding machine MIG
Measuring device L...	

QR sticker print Mini
QR sticker print large

Locations of object
Nederland
Quantity: 1


Choose report definition

Print format: PDF | Excel

There are 1 row(s) selected



Report name	Report definition
<input type="text"/>	<input type="text"/>
Object	OS
Object locatie	OJL
0-Sticker	Sticker
Continulabel	Continulabel
Eqin_QR_Groot_180	Eqin_QR_Groot_180
Eqin_QR_Klein_180	Eqin_QR_Klein_180
eqin_sticker_mini	eqin_sticker_mini
eqin_sticker_mini	test2
Object inspectie	Object Inspectie
Object-inspectie	OJ12
UnitedRentals_QR_Groot_180	UR_QR_Groot_180
UnitedRentals_sticker_mini	UR_sticker_mini

3. Choose one of the options
4. The printer settings are opened
5. Choose your printer
6. Make sure your printer prints at actual size (see image below)
7. Press Print






Bulk objects

1. Go to the menu " modify article " under the main menu " Admin "
2. Enter the object (object ID) at the top of the " ID " column and right-click on it. Choose For selected lines > Print




3. Choose one of the options
4. The printer settings are opened
5. Choose your printer
6. Make sure your printer prints at full size (see image below)
7. Click print



Printing a batch of labels

1. Find the objects you want to print a label for (see [search objects](#))
2. Select the objects, right-click and choose " For selected lines "



3. Choose one of the options
4. The printer settings are opened

Choose report definition


✕

Print format PDF Excel

There are 1 row(s) selected

Report name	Report definition
<input type="text"/>	<input type="text"/>
Object	OS
Object locatie	OJL
0-Sticker	Sticker
Continuabel	Continuabel
Eqin_QR_Groot_180	Eqin_QR_Groot_180
Eqin_QR_Klein_180	Eqin_QR_Klein_180
eqin_sticker_mini	eqin_sticker_mini
eqin_sticker_mini	test2
Object inspectie	Object Inspectie
Object-inspectie	OJ12
UnitedRentals_QR_Groot_180	UR_QR_Groot_180
UnitedRentals_sticker_mini	UR_sticker_mini

5. Choose your printer
6. Make sure your printer prints at full size (see image below)
7. Choose print



1. Objects

1.1 Object search

Filter and click

1. Go to " Objects "



2. It is easiest to find an object if you know its ID (fleet number).




+ ADD

ID	Object image	Product ID	Description	Object owner	Owner refe...	Location	MI validity da
23023596		4411233	Manual chain hoist 3t / 3 m ...	EQIN		Nederland	18-9-2025

3. It is also possible to search on another field, for example, the description or the product ID.

4. Click on the object line to go to the object page.



+ ADD

ID	Object image	Product ID	Description	Object owner	Owner refe...	Location	MI validity da
23023596		4411233	Manual chain hoist 3t / 3 m ...	EQIN		Nederland	18-9-2025

23023596 - Manual chain hoist 3t / 3 m 360°

Manual chain hoist 3t / 3 m 360°



Validity date: 18-9-2025
Current object state: Approved

Inspection history

Inspection	Date
Keuring, alleen geldig in Nederland	18-9-2024
Keuring, alleen geldig in België	9-8-2024

Owner: EQIN
ID: 23023596
Owner references
Barcode
Brand
Type
Serial Number: E14069994
Construction year: 2016
End of life
Object type: Lifting equipment (suspended load)
Measuring device t...
Status: Active
Unique item:
Cost category

QR sticker print Mini
QR sticker print large

Locations of object

Nederland
Quantity: 1

Documents


Handleiding/User manual/Handbuch
Manual Yalelift 360 (NL-DE-EN-FR)_001
Yalelift 360 3T (NL-DE-EN-FR).pdf

Marketing

Yalelift 360 Dimensional Details

Fast filter

1. Hover your mouse over the value you want to filter on (example below: " TPS 5000 ")
2. Press the right mouse button and choose " Fast Filter ".



ID	Object image	Product ID	Description	Object owner	Owner ref...	Location	HI validity date	Brand	Brand type	Serial no	Object status	Object type ID	Search tag	Created by	Created
0011				Unicus Deutschland G...			1-10-2025	Froneus	TPS 5000	00202113	Active	LAS-RSG		msc.debak	18-10-20
0022				Unicus Deutschland G...			1-10-2025	Froneus	TPS 50		Done	LAS-RSG		msc.debak	18-10-20
10020215				Food Technology	406		14-11-2017	Froneus	FR9 26		Done	LAS-TTG		msc	20-11-20
10020216				Food Technology	407		12-11-2017	Froneus	FR9 26		Done	LAS-TTG		msc	20-11-20
10040209				VEHNER BEMER	240		18-11-2017	Froneus	TT 3000	10040209	Active	LAS-TTG		msc	20-11-20

3. Filtering is now in progress

1.2 Viewing object information

If you go to an object page, you will come to the page below. Under " Inspection history ", you will find all inspections performed on this object. In the column to the right you will find other documentation.

11283886 - Generator 500 kVA 230/400V diesel stage III

Generator 500kva 230/400v Diesel Stage III



Validity date: 16-8-2025
Current object state: Approved

Owner	EQIN
ID	11283886
Owner references	
Barcode	
Brand	JCB Aggregaten
Type	GS00RS E3A
Serial Number	2656535
Construction year	2021
End of life	
Object type	Electrical more complex inspection plan NENS140
Measuring device t...	
Status	Active
Unique item	<input checked="" type="checkbox"/>
Cost category	

Locations of object: België, Quantity: 1

Inspection history


	All	Planned	Unplanned
Keuring huur / Mietinspektion / Rental inspection			16-8-2024
ID	707506		
Validity date	16-8-2025		
Inspection result	Ok		
Keuring huur / Mietinspektion / Rental inspection			1-7-2023
ID	697312		
Validity date	1-7-2024		
Inspection result	Ok		

Documents

- Certificaat / Certificate / Zertifikat
 - CE Pols (sn C4664A#004)
- Electrical diagram
 - EU FS LDW OPS JCB_EN DGS500-1 Schematic_Sync_Controller
- Handleiding / User manual / Handbuch
 - Bedienungsanleitung Rental Series 3.0
 - Gesam Volvo
 - Gesam Volvo (En)

Viewing information for selected lines

After one or more lines have been selected, a number of actions can be performed.




The description of the actions is fairly self-explanatory. The next section deals with " Printing "

Printing data


Under " Print ", you can create a report of the selected lines. Various reports are available for objects, items, object inspections, locations and relationships. Among other things, this functionality can be used to:

- Print stickers for multiple objects at once
- Get multiple certificates in one PDF
- Display certain overviews of a selection



1.3 Adding or editing objects


At the top of the object view is the " Add " button.



The screenshot shows the top navigation bar of the United Rentals system with the 'Objects' menu item highlighted. Below the navigation bar is a '+ ADD' button. A search bar is visible with a refresh icon and a dropdown menu set to 'Active'. Below the search bar is a table with the following columns: ID, Description, Object type ID, Object type description, and Object type. The table contains several rows of equipment data.


ID	Description	Object type ID	Object type description	Object type
<input type="checkbox"/> 0011		LAS-MIG	Welding equipment - MIG	Welding equipment -
<input type="checkbox"/> 0022		LAS-MIG	Welding equipment - MIG	Welding equipment -
<input type="checkbox"/> 0-045	Digital multimeter Fluke 177	EKK	Electrical inspection + calibration	Electrical inspection
<input type="checkbox"/> 0-073	Scopemeter Fluke 123	EKK	Electrical inspection + calibration	Electrical inspection
<input type="checkbox"/> 01.01.5133		Hijs	Lifting equipment (suspended loa...	Lifting equipment (sa
<input type="checkbox"/> 01.01.5134		Hijs	Lifting equipment (suspended loa...	Lifting equipment (sa
<input type="checkbox"/> 01.01.5135		Hijs	Lifting equipment (suspended loa...	Lifting equipment (sa
<input type="checkbox"/> 01.01.5136		Hijs	Lifting equipment (suspended loa...	Lifting equipment (sa
<input type="checkbox"/> 02.07.5391		EKH	Hoisting and lifting certified equip...	Hoisting and lifting o

At the top of an object page is the " edit " button.



The screenshot shows the details page for object 23122203, titled '23122203 - TIG torch ITW 21 Flex 16 m Fronius pen'. The page includes a main image of the TIG torch, a 'Validity date' section with 'Current object state' set to 'No state', and a 'Start unscheduled inspection' button. On the right, there are sections for 'Owner' (EDIN), 'Owner references', 'Barcode', 'Brand' (Fronius), 'Type' (CI230FX 16F), 'Serial Number', 'Construction year' (2024), 'End of life', 'Object type' (Not subject to inspection), 'Measuring device L...', 'Status' (Active), 'Unique item' (checkbox), and 'Cost category'. There are also QR sticker print options (Mini and Large), 'Locations of object' (België, Quantity: 1), 'Documents' (Onderhoud/Maintenance/Wartung), and a 'Move log' section.

For some fields, you can only choose values from a list.




The screenshot shows the edit form for object 0001. The form includes fields for 'Owner' (0001 - EQIN), 'Brand' (Fronius - Fronius), 'Type' (3H 3H), 'Serial number' (4TECX 4tec), 'Construction year' (AMN AMN), 'End of life' (A. SYKES A. SYKES), 'ID' (AB AB), 'Owner reference' (ABB ABB), 'Object type' (ABB metra watt ABB metra watt), 'Barcode', and 'Note'. There is also a 'Description' field with a dropdown menu, a 'Status' field (A - InChief), a 'Cost category' search field, and a 'Product' field (6632096 - TIG torch ITW 21 Flex 16 m Fronius pen). The form also includes a 'Search arguments' field.

1.4 Conducting an inspection

Inspection in the app (tablet or cell phone)

Go to Relations and choose the relation on whose site you are. Then choose Objects. Click on the magnifying glass to search by fleet number or click on the barcode to scan a QR code. Then scan the QR code or enter the fleet number.




You will arrive at the object page. Scroll down and create a new inspection.




Remove steps (applicable for field service only)

If a client opts for, say, only a basic inspection plan, the remaining steps should be removed. You can do this using the method below. Remove all steps so that you are left with only the ones you want to perform. You should always perform the step "Administratief".

App



Web version



Conducting an inspection in the web version

Go to the object page of the object you want to inspect (under " Object search ", you will find how to get here). Then choose " Start inspection according to schedule " or " Start unscheduled inspection ".

23124100 - MWK charger quick and easy 230V / 12V 18V

MWK charger quick and easy 230V / 12V 18V



Owner	EQIN
ID	23124100
Owner references	
Barcode	
Brand	Milwaukee
Type	M12-18 FC
Serial Number	400452385265128
Construction year	2024
End of life	
Object type	Electrical inspection plan NEN3140
Measuring device t...	
Status	Active
Unique item	<input type="checkbox"/>
Cost category	

Validity date: 30-6-2025
Current object state: Approved

Inspection history | All | Planned | Unplanned

Elektrisch (stekker/stecker) / Electric (plug)	7-6-2024
ID	681155
Validity date	30-6-2025
Inspection result	Ok

Certificates

Elektrisch (stekker/stecker) / Electric (plug)

 Start inspection according to schedule

 Start unscheduled inspection

QR sticker print Mini 

QR sticker print large 

Locations of object

 **Nederland** 
Quantity: 1 

Documents

Handleiding / User manual / Handbuch
 [M12-18FC](#)

Marketing
 [115-1165 M12_18_FC](#)
 [Oeladtid accu per lader](#)

Onderhoud / Maintenance / Wartung
 [Sticker instructie 115-1165 M12-18FC](#)

Picture
 [add icon](#)

Move log

15-8-2024 10:35:39	Quantity: 1
:	NLD Nederland
:	EQIN

Remove steps (for field service only)

See Remove steps and scroll to the web version ([Click here](#)).

Answering questions

Click on a step to answer the questions one by one.

← Object Inspectie  

QUESTIONS | RESULT

Basic (19/19)  


202 - Aansluitstekker    

203 - Trekontlasting    

204 - Primaire kabel    


205 - Mechanische toestand, plaatwerk, bestickering, scharnieren, sluitingen    

Or answer all the questions for a step at once.




Result

After you answer all the questions, Eqinfo will automatically determine the result. You can edit this result.




Verifying that an inspection has been closed

Go to " Maintenance " and choose " Object Inspections "




Enter your name under " Inspector Description " and select " Active " at the top of the page. If any inspections appear, they have not yet been closed correctly. Decide whether you want to close or delete the inspection. Click on the inspection to reopen it.




If you select " Wait for measurement instrument " instead of " Active ", all inspections for which measurements are yet to be processed will appear

Removing an inspection

Inspections mustn't be left open. Therefore, it is sometimes necessary to remove an incomplete inspection.







Deleting an inspection on the website via inspection history

Go to the page of the object for which you want to delete an inspection (see Object search). Click on the History inspection button at the bottom of the page. Then right-click on the inspection you want to delete. Choose For selected lines > Delete.

Make sure you remove the correct inspection!



2. Locations

2.1 Finding locations



This works the same as object search ([see section 1.1](#)).


2.2 Viewing location data

This works as viewing object data ([see section 1.2](#)).

3. Relations

3.1 Finding relations

In the menu " Relations " you see an overview of the different relations to which you can attach objects and locations. Each user only has insight into the relations that apply to him or her.

A screenshot of the United Rentals 'Relations' page. The page has a dark navigation bar with 'Relations' highlighted in a red box. Below the navigation bar is a '+ ADD' button and a search bar with a refresh icon, a dropdown menu set to 'Active', and a 'Search...' input field. The main content is a table with columns: ID, Name, Address, Postal code city, Country, and Relation status. The table contains 16 rows of data, each with a checkbox in the ID column. The data is as follows:

ID	Name	Address	Postal code city	Country	Relation status
<input type="checkbox"/> 000000442	Ijmuidense Rondvaart Maatschappij B...				Actief
<input type="checkbox"/> 000000443	ABV Haukes Inspectiediensten B.V.				Actief
<input type="checkbox"/> 000000444	Westland Metaalbewerking				Actief
<input type="checkbox"/> 000000464	Hoefmederij de Koning				Actief
<input type="checkbox"/> 000000478	Van Kempen Las en Montagebedrijf				Actief
<input type="checkbox"/> 000000486	Wouters Laswerken				Actief
<input type="checkbox"/> 000000487	Chimec SpA				Actief
<input type="checkbox"/> 000000878	Vattenfall Hollandse Kust Zuid				Actief
<input type="checkbox"/> 00000446	Hollestelle Konstruktie B.V.				Actief
<input type="checkbox"/> 000084449	Exel Techniek				Actief
<input type="checkbox"/> 0001	EQIN	Theemsweg 2	3197 KM BOTLEK ROTT...	Nederland	Actief
<input type="checkbox"/> 00023361	SCHOUTEN FLEXDIENSTEN	KRUIJNINGENSTRAAT 2...	3086 KT ROTTERDAM	Nederland	Actief
<input type="checkbox"/> 0003	Tool Management: Sitech				Actief
<input type="checkbox"/> 00109	Red D Arc	Nijverheidsweg 32 E	3251 LP STELLENDAM	Nederland	Actief
<input type="checkbox"/> 001182	Lo Minck Engineering B.V.				Actief

This works the same as object search ([see section 1.1](#)).


3.2 Viewing relation data

This works as viewing object data ([see section 1.2](#)).

4. Catalog


4.1 Viewing the product catalog by topic

To search products by subject in the online catalog, click on "Catalog" in the main menu. From here you can navigate to the different product groups and subgroups.



4.2 Searching for items in the catalog

To search the catalog in detail, enter the product name or product number in the search bar.




This works the same as object search ([see section 1.1](#)).


5. Maintenance

5.1 Inspection

It is possible to inspect objects via Maintenance / Object Inspections



Enter the Object ID to inspect the object. For more information on inspecting: see [Conducting an inspection.](#)



5.2 Open inspections

Under " Maintenance " / " Object Inspections " you will find all open inspections. See [Verifying that an inspection has been closed](#) for more information.